The Size-It software is designed to allow quick and easy sizing of interior fuel piping using the Gastite CSST flexible piping system. To size a system, simply define the components contained in the system using the following instructions:

The system must always start with a gas supply followed by a trunk line. Appliance runs are attached at the end of the trunk lines. To define and size a system:

1. Set the general system data by clicking on the General Settings data tab; enter the appropriate values by typing or selecting them from the item lists.

2. Define the system configuration by clicking on the Piping Components data tab.

3. Enter the data for each component by typing or selecting the appropriate values for each data item.

4. Click the Next command button to add another component, or click the Enter command button to end with the current component.

5. The results will automatically be calculated when the Next, Previous, or Enter command buttons are used.

6. Use the Next and Previous command buttons to browse through the components.

To print the results, select the Print item from the File menu list. To save the piping configuration for future use or reference, select the Save or Save As item from the File menu list.

If you have trouble using the software, please feel free to contact us. Our contact information can be displayed by selecting the How To Reach Us item from the Help menu list or by calling Gastite Technical Support at 800.662.0208.